

Chapter 1

Robot Code

Robot.java

```
1 package frc.robot;
2
3 import edu.wpi.first.wpilibj.TimedRobot;
4 import frc.robot.Mode.Autonomous;
5 import frc.robot.Mode.Disabled;
6 import frc.robot.Mode.Simulation;
7 import frc.robot.Mode.Teleop;
8 import frc.robot.Mode.Test;
9 import frc.robot.Mode.Onabot;
10
11 public class Robot extends TimedRobot {
12     @Override public void robotInit      () { Onabot      .Initialize(); }
13     @Override public void robotPeriodic  () { Onabot      .Periodic();   }
14
15     @Override public void autonomousInit  () { Autonomous .Initialize(); }
16     @Override public void autonomousPeriodic () { Autonomous .Periodic();   }
17
18     @Override public void disabledInit    () { Disabled   .Initialize(); }
19     @Override public void disabledPeriodic () { Disabled   .Periodic();   }
20
21     @Override public void teleopInit      () { Teleop     .Initialize(); }
22     @Override public void teleopPeriodic  () { Teleop     .Periodic();   }
23
24     @Override public void testInit        () { Test       .Initialize(); }
25     @Override public void testPeriodic    () { Test       .Periodic();   }
26
27     @Override public void simulationInit   () { Simulation .Initialize(); }
28     @Override public void simulationPeriodic () { Simulation .Periodic();   }
29 }
```

Onabot.java

```
1 package frc.robot.Mode;
2
3 import frc.robot.Hardware.AutonChooser;
4 import frc.robot.Hardware.Driver;
5 import frc.robot.Hardware.Elevator;
6 import frc.robot.Hardware.Navigation;
7 import frc.robot.Hardware.Stage;
8 import frc.robot.Hardware.Swerve;
9
10 public class Onabot {
11
12     public static void Initialize () {
13         AutonChooser .Initialize();
14         Driver       .Initialize();
15         Elevator     .Initialize();
16         Navigation   .Initialize();
17         Swerve       .Initialize();
18
19         // Lidar      .Initialize();
20         // Sonar      .Initialize();
21         // Vision     .Initialize();
22     }
23
24     public static void Periodic () {
25         AutonChooser .Display();
26         Driver       .Display();
27         Elevator     .Display();
28         Navigation   .Display();
29         Swerve       .Display();
30
31         // Lidar      .Display();
32         // Sonar      .Display();
33         // Vision     .Display();
34
35         Stage.Display();
36     }
37
38 }
```

Autonomous.java

```
1 package frc.robot.Mode;
2
3 import frc.robot.Hardware.AutonChooser;
4 import frc.robot.Hardware.Autopilot;
5 import frc.robot.Hardware.Elevator;
6 import frc.robot.Hardware.Stage;
7 import frc.robot.Hardware.Swerve;
8 import frc.robot.Hardware.Path;
9
10 public class Autonomous {
11
12     public static String
13         AutonChoice = "DoNothing";
14
15     public static void Initialize () {
16         AutonChoice = AutonChooser.chooser.getSelected();
17         Stage.Initialize();
18     }
19
20     public static void Periodic () {
21         Stage.Begin();
22
23         switch ( AutonChoice ) {
24             case "Nothing" : Path.Nothing(); break;
25             case "Any_1st" : Path.Any_1st(); break;
26             case "Any_2nd" : Path.Any_2nd(); break;
27             case "Lft_1st" : Path.Lft_1st(); break;
28             case "Lft_2nd" : Path.Lft_2nd(); break;
29             case "Ctr_1st" : Path.Ctr_1st(); break;
30             case "Ctr_2nd" : Path.Ctr_2nd(); break;
31             case "Rgt_1st" : Path.Rgt_1st(); break;
32             case "Rgt_2nd" : Path.Rgt_2nd(); break;
33         }
34
35         Stage.Next();
36
37         // EXECUTE COMMANDS
38         Elevator.Periodic();
39         Swerve.UpdateRobotRelative( Autopilot.vx, Autopilot.vy, Autopilot.vt );
40     }
41
42 }
```

Teleop.java

```
1 package frc.robot.Mode;
2
3 import edu.wpi.first.wpilibj.Joystick;
4 import edu.wpi.first.wpilibj.XboxController;
5 import frc.robot.Hardware.Driver;
6 import frc.robot.Hardware.Elevator;
7 import frc.robot.Hardware.Settings;
8
9 public class Teleop {
10
11     public static Joystick      DriveStick;
12     public static XboxController ManipStick;
13
14     public static double
15         Xratio,
16         Yratio,
17         Tratio;
18
19     public static void Initialize () {
20         DriveStick = new Joystick(      Settings.DriveStickID );
21         ManipStick = new XboxController( Settings.ManipStickID );
22     }
23
24     public static void Periodic () {
25         Xratio = -DriveStick.getY();
26         Yratio = -DriveStick.getX();
27         Tratio = -DriveStick.getTwist();
28
29         // UPDATE ALL COMPONENTS
30         Driver  .Periodic();
31         Elevator .Periodic();
32     }
33
34     public static void Display () {
35     }
36 }
```

Autopilot.java

The Autopilot methods are used in Autonomous mode to set the chassis speed variable found in this class. Values are sent to motor controllers in Autonomous.Periofic().

```
1 package frc.robot.Hardware;
2
3 public class Autopilot {
4
5     public static double LastHeading = 0;
6
7     public static double vx = 0;
8     public static double vy = 0;
9     public static double vt = 0;
10
11     //
12     // HeadingDiff is a simple method that calculates the angle difference
13     // between the current and desired heading. This can be used anywhere.
14     //
15     public static double HeadingDiff ( double SP ) {
16
17         // CALCULATE TURN VALUES
18         double PV = Navigation.GetDirection(); // Current state (Initial)
19         SP = ( SP + 360 ) % 360; // Ensure SP is between 0 and 360
20         double diff = -( SP - PV ); // Why is this negated? Should setInverted have been used?
21
22         // SMALLEST ANGLE TO SWIVEL: -180 to 180
23         double minTurn = ( diff + 180 ) % 360 - 180;
24         return minTurn;
25     }
26
27     //
28     // This is a simple method for driving somewhat straight without using
29     // a gyroscope. There may be situations where it is good enough.
30     //
31     public static void DriveSortaStraight ( double Vx, double Vy ) {
32         vx = Vx; vy = Vy; vt = 0;
33     }
34
35     // Consider turning this into a pseudo tank drive for purposes of
36     // driving in a straight line using the gyroscope.
37     public static void DriveStraight ( double Vx, double Vy ) {
38         vx = Vx; vy = Vy; vt = 0;
39     }
40
41     //
42     //
43     //
44     public static void DriveNorth ( double Speed ) {
45         vx = +Speed; vy = 0; vt = 0;
46     }
47
48     public static void DriveSouth ( double Speed ) {
49         vx = -Speed; vy = 0; vt = 0;
50     }
51
52     public static void DriveWest ( double Speed ) {
53         vx = 0; vy = +Speed; vt = 0;
54     }
55
56     public static void DriveEast ( double Speed ) {
57         vx = Speed; vy = -Speed; vt = 0;
58     }
59
60     //
61     //
62     //
63     public static void DriveNorthWest ( double Speed ) {
```

```

64     double radians = Math.toRadians( 45 );
65     double speed    = Speed * Math.cos( radians );
66     vx = +speed; vy = +speed; vt = 0;
67 }
68
69 public static void DriveNorthEast ( double Speed ) {
70     double radians = Math.toRadians( 45 );
71     double speed    = Speed * Math.cos( radians );
72     vx = +speed; vy = -speed; vt = 0;
73 }
74
75 public static void DriveSouthWest ( double Speed ) {
76     double radians = Math.toRadians( 45 );
77     double speed    = Speed * Math.cos( radians );
78     vx = -speed; vy = +speed; vt = 0;
79 }
80
81 public static void DriveSouthEast ( double Speed ) {
82     double radians = Math.toRadians( 45 );
83     double speed    = Speed * Math.cos( radians );
84     vx = -speed; vy = -speed; vt = 0;
85 }
86
87 //
88 // TurnToHeading sets the turn power variable in Autonomous mode to reach
89 // the desired heading using the shortest wheel swivel.
90 //
91 public static void TurnToHeading ( double NewHeading ) {
92     double minTurn = HeadingDiff( NewHeading );
93     double turnMag = Math.abs ( minTurn );
94     double turnDir = Math.signum( minTurn );
95
96     // MINIMIZE WHEEL SWIVEL: +120 becomes -60
97     if ( turnMag > 90 ) {
98         turnMag = 180 - turnMag; // Turn smaller angle
99         turnDir = -1;           // and reverse swivel
100     }
101
102     // DETERMINE POWER USING PSEUDO PID CONTROLLER
103     if ( turnMag > 20 ) { vt = 0.15; }
104     else if ( turnMag > 10 ) { vt = 0.08; }
105     else if ( turnMag > 1 ) { vt = 0.08; }
106     else { vt = 0.00; }
107
108     LastHeading = NewHeading;
109     vx = 0; vy = 0; vt *= turnDir;
110 }
111
112 //
113 // Stop sets the robot speed vector to zero. This is useful only in Autonomous
114 // mode. It should not be used elsewhere.
115 //
116 public static void Stop () {
117     vx = 0; vy = 0; vt = 0;
118 }
119
120 //
121 // These methods rotate the robot at a constant counter-clockwise speed and
122 // clockwise speed respectively. This is only useful in Autonomous mode.
123 //
124 public static void TurnLeftAtSpeed ( double Speed ) {
125     vx = 0; vy = 0; vt = +Speed;
126 }
127
128 public static void TurnRightAtSpeed ( double Speed ) {
129     vx = 0; vy = 0; vt = -Speed;
130 }
131

```

```
132 // public static void AdjustTurnSpeed( double Speed ) {
133 //     // double error = Speed - Navigation.GetTurnSpeed();
134 //     // LastPowerT += error * 0.0001;
135 // }
136
137 // public static void DriveStraight ( double Speed, double Heading ) {
138
139 // }
140
141 }
```


Driver.java

```

1 package frc.robot.Hardware;
2
3 import frc.robot.Driver.RobotRelative;
4
5 public class Driver {
6
7     // public static String SelectedDriver = "RobotRel";
8
9     // public static final String kRobotRel = "RobotRelative";
10    // public static final String kFieldRel = "FieldRelative";
11    // public static final String kAubrey = "Aubrey";
12    // public static final String kNate = "Nate";
13    // public static final String kSteensma = "Steensma";
14    // public static final SendableChooser<String> chooser = new SendableChooser<>();
15
16    public static void Initialize () {
17        // chooser.setDefaultOption("RobotRel", kRobotRel );
18        // chooser.addOption      ("FieldRel", kFieldRel );
19        // chooser.addOption      ("Aubrey", kAubrey );
20        // chooser.addOption      ("Nate", kNate );
21        // chooser.addOption      ("Steensma", kSteensma );
22        // SmartDashboard.putData ("DRIVER", chooser );
23    }
24
25    public static void Periodic () {
26        RobotRelative.Periodic();
27        // switch ( "RobotRel" ) {
28        //     case "RobotRel" : RobotRelative .Periodic();
29        //     case "FieldRel" : FieldRelative .Periodic();
30        //     case "Aubrey" : Aubrey .Periodic();
31        //     case "Nate" : Nate .Periodic();
32        //     case "Steensma" : Steensma .Periodic();
33        // }
34    }
35
36    public static void Display () {
37        // SmartDashboard.putString("Driver", chooser.getSelected() );
38    }
39
40 }

```

Elevator.java

```
1 package frc.robot.Hardware;
2
3 import frc.robot.Elevator.Arm;
4 import frc.robot.Elevator.Claw;
5 import frc.robot.Elevator.Lift;
6 import frc.robot.Elevator.Roller;
7
8 public class Elevator {
9
10     public static void Initialize () {
11         Arm        .Initialize();
12         Claw        .Initialize();
13         Lift        .Initialize();
14         Roller      .Initialize();
15     }
16
17     public static void Periodic () {
18         Arm        .Periodic();
19         Claw        .Periodic();
20         Lift        .Periodic();
21         Roller      .Periodic();
22     }
23
24     public static void Display () {
25         Arm        .Display();
26         Claw        .Display();
27         Lift        .Display();
28         Roller      .Display();
29     }
30
31     public static void Reset () {
32         Arm        .Reset(); // SetHI
33         Claw        .Reset(); // Drop
34         Lift        .Reset(); // SetLO
35         Roller      .Reset(); // Stop
36     }
37
38     //
39     //
40     //
41     public static void Preset1 () {
42         Lift        .SetLO();
43     }
44
45     public static void Preset2 () {
46         Lift        .SetLO();
47     }
48
49     public static void Preset3 () {
50         Lift        .SetHI();
51     }
52
53 }
```

Arm.java

```

1 package frc.robot.Elevator;
2
3 import com.ctre.phoenix.motorcontrol.ControlMode;
4 import com.ctre.phoenix.motorcontrol.can.TalonSRX;
5
6 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
7 import frc.robot.Hardware.Settings;
8
9 public class Arm {
10
11     public static TalonSRX
12         Arm;
13
14     public static double
15         angle,
16         direction,
17         displacement = 0,
18         LO          = 0,
19         MD          = 60,
20         HI          = 90,
21         maximum     = -22000,
22
23         PosPV = 0, PosSP = HI, PosER = 0,
24         VelPV = 0, VelSP = 0, VelER = 0,
25
26         kF          = 0,
27         tolerance = 5, // degrees
28
29         Power       = 0;
30
31     //
32     //
33     //
34     public static void Initialize () {
35         Arm = new TalonSRX( Settings.Arm_CANID );
36         Arm .setInverted( true );
37         Arm .setSelectedSensorPosition( 90 );
38     }
39
40     public static void Periodic () {
41
42         // POSITION VALUES
43         PosPV = GetPosition();
44         PosER = PosSP - PosPV;
45         VelPV = GetVelocity();
46
47         // VELOCITY SET POINT (Depends on PosER)
48         if ( PosER > 0 ) { VelSP = +1200; }
49         if ( PosER < 0 ) { VelSP = -700; }
50
51         // ADJUST VELOCITY
52         VelER = VelSP - VelPV;
53         Power += 0.00005 * VelER;
54
55         // MAXIMUM POWER
56         if ( Power < -0.90 ) { Power = -0.90; }
57         if ( Power > +0.90 ) { Power = +0.90; }
58
59         // CUT POWER WHEN WITHIN RANGE
60         if ( Math.abs(PosER) < 5 ) { Power = 0; }
61         if ( PosSP == LO & PosPV < LO ) { Power = 0; }
62
63         // SET POWER
64         Arm.set( ControlMode.PercentOutput, Power );
65     }

```

```
66
67     public static void Display () {
68         SmartDashboard.putNumber("Arm_Pos_PV", GetPosition() );
69         SmartDashboard.putNumber("Arm_Pos_SP", PosSP );
70
71         SmartDashboard.putNumber("Arm_Vel_PV", GetVelocity() );
72         SmartDashboard.putNumber("Arm_Vel_SP", VelSP );
73
74         SmartDashboard.putNumber("ARM_POWER", Power );
75         SmartDashboard.putNumber("Arm_PosER", PosER );
76         SmartDashboard.putNumber("Arm_VelER", VelER );
77     }
78
79     //
80     // POSITION          VELOCITY
81     // 0 horizontal + is movign up
82     // 90 vertical - is moving down
83     public static double GetPosition () {
84         double PV = Arm.getSelectedSensorPosition();
85         PosPV = 90 - PV / maximum * 90;
86         return PosPV;
87     }
88
89     public static double GetVelocity () {
90         VelPV = Arm.getSelectedSensorVelocity();
91         return VelPV;
92     }
93
94     public static void SetPosition ( double pos ) {
95         PosSP = pos;
96     }
97
98     //
99     //
100    //
101    public static void Reset () {
102        SetHI();
103    }
104
105    public static void SetHI () {
106        Power = 0.35;
107        PosSP = HI;
108    }
109
110    public static void SetMD () {
111        Power = 0.00;
112        PosSP = MD;
113    }
114
115    public static void SetLO () {
116        Power = 0.10;
117        PosSP = LO;
118    }
119
120 }
```

Claw.java

```

1 package frc.robot.Elevator;
2
3 import edu.wpi.first.wpilibj.Compressor;
4 import edu.wpi.first.wpilibj.DoubleSolenoid;
5 import edu.wpi.first.wpilibj.DoubleSolenoid.Value;
6 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
7 import edu.wpi.first.wpilibj.PneumaticsModuleType;
8
9 public class Claw {
10
11     // This is only needed if we want the ability to turn off the compressor,
12     // change the pressure sensor, or query the compressor status.
13     public static Compressor Comp = new Compressor( 0, PneumaticsModuleType.CTREPCM );
14
15     // Order is forward channel and the reverse channel
16     static DoubleSolenoid Lft = new DoubleSolenoid( PneumaticsModuleType.CTREPCM, 0, 1 );
17     static DoubleSolenoid Rgt = new DoubleSolenoid( PneumaticsModuleType.CTREPCM, 3, 4 );
18     // DoubleSolenoid exampleDoublePH = new DoubleSolenoid( 9, PneumaticsModuleType.REVPH, 4, 5 );
19
20     public static Value
21         State = Value.kForward;
22
23     //
24     //
25     //
26     public static void Initialize () {
27         Drop();
28     }
29
30     public static void Periodic () {
31         Lft.set( State );
32         Rgt.set( State );
33     }
34
35     public static void Display () {
36         String state = "Off";
37         if ( State == Value.kForward ) { state = "OPEN"; }
38         if ( State == Value.kReverse ) { state = "CLOSE"; }
39         SmartDashboard.putString( "CLAW", state );
40     }
41
42     //
43     //
44     //
45     public static void Drop () { State = Value.kReverse; }
46     public static void Grab () { State = Value.kForward; }
47     public static void Stop () { State = Value.kOff; }
48
49     public static void Reset () { Drop(); }
50
51     public static void Toggle () {
52         State = State == Value.kForward ? Value.kReverse : Value.kForward;
53     }
54 }

```

Lift.java

```
1 package frc.robot.Elevator;
2
3 import com.ctre.phoenix.motorcontrol.VictorSPXControlMode;
4 import com.ctre.phoenix.motorcontrol.can.VictorSPX;
5
6 import edu.wpi.first.wpilibj.Ultrasonic;
7 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
8 import frc.robot.Hardware.Settings;
9
10 public class Lift {
11
12     public static VictorSPX
13         liftMotorL,
14         liftMotorR;
15
16     public static double    SP;
17     public static double    power = 0;
18
19     public static Ultrasonic Sonar;
20
21     public static double
22         HI = 27.0,
23         MD = 10.0,
24         LO = 4.5;
25
26     public static double
27         kP = 0.2;
28
29     public static double
30         direction,
31         displacement,
32         ratio,
33         tolerance;
34
35     //
36     //
37     //
38     public static void Initialize () {
39         liftMotorL = new VictorSPX( Settings.LiftL_CANID );
40         liftMotorR = new VictorSPX( Settings.LiftR_CANID );
41
42         Sonar = new Ultrasonic(
43             Settings.LiftSonar_DIO[0], // Input
44             Settings.LiftSonar_DIO[1]  // Output
45         );
46
47         Ultrasonic.setAutomaticMode( true );
48
49         SP = LO;
50     }
51
52     public static void Periodic () {
53
54         // READ FROM SENSOR
55         double PV = GetPosition();
56
57         // CALCULATE DISPLACEMENT AND PSEUDO VELOCITY
58         displacement = SP - PV; // Displacement in inches
59         ratio = displacement / 28;
60
61         direction = Math.signum( displacement ); // +1 for up; -1 for down
62         // ratio = displacement / ( HI - LO ); // Displacement ratio ( 0 to 1 )
63
64         // SIMPLE PID CONTROLLER BASED RATIO
65         power = direction * 0.80;
```

```

66
67     if ( Math.abs( displacement ) < 2 ) { power = 0; }
68
69     // SET MOTOR POWER
70     liftMotorL.set( VictorSPXControlMode.PercentOutput, power );
71     liftMotorR.set( VictorSPXControlMode.PercentOutput, power );
72 }
73
74 //
75 //
76 //
77 // public static void increase_power () { power += 0.001; }
78 // public static void decrease_power () { power -= 0.001; }
79
80 public static void Display () {
81     SmartDashboard.putNumber("Lift_PV", GetPosition() );
82     SmartDashboard.putNumber("Lift_SP", SP );
83     SmartDashboard.putNumber("Lift_Dir", direction );
84     SmartDashboard.putNumber("Lift_Pow", power );
85 }
86
87 //
88 //
89 //
90 public static double GetPosition () {
91     return Sonar.getRangeInches();
92 }
93
94 //
95 // This intent of these methods is to have presets of where
96 // the lift mechanism is intended to stop.
97 //
98 public static void SetPosition ( double pos ) {
99     SP = pos;
100 }
101
102 public static void Reset () {
103     SetLO();
104 }
105
106 public static void SetHI () {
107     SP = HI;
108 }
109
110 public static void SetMD () {
111     SP = MD;
112 }
113
114 public static void SetLO () {
115     SP = LO;
116 }
117
118 }

```

Roller.java

```
1 package frc.robot.Elevator;
2
3 import com.ctre.phoenix.motorcontrol.ControlMode;
4 import com.ctre.phoenix.motorcontrol.can.VictorSPX;
5
6 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
7 import frc.robot.Hardware.Settings;
8
9 public class Roller {
10
11     public static VictorSPX
12         Lroller ,
13         Rroller;
14
15     public static double
16         Power;
17
18     public static void Initialize () {
19         Lroller = new VictorSPX( Settings.Roller_CANID[0] );
20         Rroller = new VictorSPX( Settings.Roller_CANID[1] );
21
22         Power = 0;
23
24         Lroller.setInverted( false );
25         Rroller.setInverted( true );
26     }
27
28     public static void Periodic () {
29         Lroller.set( ControlMode.PercentOutput, Power );
30         Rroller.set( ControlMode.PercentOutput, Power );
31     }
32
33     public static void Display () {
34         SmartDashboard.putNumber( "Roller_Power", Power );
35     }
36
37     //
38     //
39     //
40     public static void Reset () { Stop(); }
41     public static void Drool () { Power = +0.20; }
42     public static void Spit () { Power = +1.00; }
43     public static void Suck () { Power = -0.30; }
44     public static void Stop () { Power = +0.00; }
45 }
```


EncTalonFX.java

```
1 package frc.robot.Hardware;
2
3 import com.ctre.phoenix.sensors.CANCoder;
4
5 public class EncTalonFX {
6
7     public CANCoder FalconEncoder;
8     public final static int kUnitsPerRevolution = 2048;
9
10    public EncTalonFX ( int CanBusID ) {
11        FalconEncoder = new CANCoder( CanBusID );
12    }
13
14 }
```

Module.java

```

1 package frc.robot.Hardware;
2
3 import com.ctre.phoenix.motorcontrol.ControlMode;
4 import com.ctre.phoenix.motorcontrol.NeutralMode;
5 import com.ctre.phoenix.motorcontrol.can.WPI_TalonFX;
6
7 import edu.wpi.first.math.controller.PIDController;
8 import edu.wpi.first.math.kinematics.SwerveModuleState;
9 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
10
11 public class Module {
12
13     public EncTalonFX    SteerEncoder;
14     public int           ModuleNumber;
15     public String        ModuleName;
16     public WPI_TalonFX   DriveMotor;
17     public WPI_TalonFX   SteerMotor;
18     public PIDController SteerPID;
19     public double         TurnDiff    = 0;
20     public double         SpeedPlus   = 0;
21     public double         LastPosition = 0;
22     public boolean        still_turning_flag = false;
23
24     public double         DriveRatio = 0;
25     public double         SteerRatio = 0;
26     public double         minTurn    = 0;
27     public double         reverse     = 0;
28     public double         turnDir     = 0;
29     public double         turnMag     = 0;
30     public double         Power       = 0;
31
32     public double         SteerOffset = 0;
33
34     public Module ( String ModuleName, int ModuleNumber ) {
35
36         // REMEMBER VALUES
37         this.ModuleName = ModuleName;
38         this.ModuleNumber = ModuleNumber;
39
40         // ID 'S FOLLOW A PATTERN BASED ON MODULE NUMBERS
41         int DriveMotorID = ModuleNumber *2 -1;
42         int SteerMotorID = ModuleNumber *2 -0;
43
44         // DEFINE AND CONFIGURE DRIVE MOTOR
45         DriveMotor = new WPI_TalonFX ( DriveMotorID );
46         DriveMotor.setNeutralMode( NeutralMode.Brake );
47
48         // DEFINE AND CONFIGURE STEER MOTOR
49         SteerMotor = new WPI_TalonFX ( SteerMotorID );
50         SteerMotor.setNeutralMode( NeutralMode.Brake );
51
52         // DEFINE STEER ENCODER
53         SteerEncoder = new EncTalonFX ( ModuleNumber );
54     }
55
56     public void Display () {
57         // STEER ENCODER
58         SmartDashboard.putNumber(ModuleName + "PV", this.SteerEncoder.FalconEncoder.getAbsolutePosition() );
59     }
60
61     public void ResetDriveEncoder () {
62         // DriveMotor
63     }
64
65     public double GetDirection () {

```

```

66         return SteerEncoder.FalconEncoder.getAbsolutePosition();
67     }
68
69     public void Update ( SwerveModuleState state ) {
70
71         // CALCULATE DRIVE VALUES
72         DriveRatio = state.speedMetersPerSecond;
73         reverse     = 1;
74
75         // CALCULATE TURN VALUES
76         double SP = state.angle.getDegrees(); // Desired state (Final)
77         double PV = GetDirection();           // Current state (Initial)
78         PV = ( PV + 360 ) % 360; // Ensure SP is between 0 and 360
79         SP = ( SP + 360 ) % 360; // Ensure SP is between 0 and 360
80
81         // SMALLEST ANGLE TO SWIVEL: -180 to 180
82         minTurn = ( PV - SP + 180 ) % 360 - 180;
83         turnMag = Math.abs ( minTurn );
84         turnDir = Math.signum( minTurn );
85
86         // MINIMIZE WHEEL SWIVEL: +120 becomes -60
87         if ( turnMag > +90 ) {
88             turnMag = 180 - turnMag; // Turn smaller angle
89             turnDir  = -1;           // and reverse swivel
90             reverse  = -1;           // and reverse drive
91         }
92
93         // DETERMINE POWER USING PSEUDO PID CONTROLLER
94         double SteerRatio = turnMag / 200;
95
96         // INCREASE STEERE OFFSET IF NOT MOVING
97         // double CurrentTurnSpeed = SteerMotor.getSelectedSensorVelocity();
98         // if ( CurrentTurnSpeed == 0 & turnMag > 1 ) {
99         //     SteerOffset += 0.0005;
100        // }
101
102        // ONE DEGREEE OFF IS GOOD ENOUGH
103        // if ( turnMag < 5 ) {
104        //     // SteerOffset = 0;
105        //     // SteerRatio  = 0.10;
106        //     // turnDir     = 1;
107        // }
108
109        // SET MOTOR CONTROLLERS
110        DriveMotor.set( ControlMode.PercentOutput, DriveRatio * reverse );
111        SteerMotor.set( ControlMode.PercentOutput, SteerRatio * turnDir );
112    }
113
114 }

```

Navigation.java

```
1 package frc.robot.Hardware;
2
3 import com.kauailabs.navx.frc.AHRS;
4 import edu.wpi.first.wpilibj.SPI;
5 import edu.wpi.first.wpilibj.Ultrasonic;
6 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
7
8 public class Navigation {
9
10     public static Ultrasonic
11         FrontSonar;
12
13     public static double
14         Offset = 0;
15
16     public static AHRS NavX;
17
18     public static void Initialize () {
19         NavX = new AHRS( SPI.Port.kMXP );
20         NavX.calibrate();
21         Reset();
22
23         // FrontSonar = new Ultrasonic(
24             //     Settings.FrontSonar_DIO[0], // Input
25             //     Settings.FrontSonar_DIO[1] // Output
26         // );
27     }
28
29     public static void Periodic () {}
30
31     public static void Display () {
32         SmartDashboard.putNumber( "Nav-Yaw",    GetDirection() );
33         SmartDashboard.putNumber( "Nav-Pitch",   GetPitch() );
34     }
35
36
37 //
38 // SUPPORT METHODS
39 //
40     public static void Reset () { NavX.reset(); }
41
42     public static double GetPitch () { return NavX.getPitch(); } // Forward tilt : - is up
43     public static double GetRoll () { return NavX.getRoll(); } // Side-to-side : + is ?
44     public static double GetYaw () { return -NavX.getYaw(); } // Twist : + is CCW
45
46     public static double GetDirection () {
47         return GetYaw();
48     }
49 }
```

Path.java

```

1 package frc.robot.Hardware;
2
3 import frc.robot.Elevator.Arm;
4 import frc.robot.Elevator.Lift;
5 import frc.robot.Elevator.Roller;
6
7 public class Path {
8
9     static double counter = 0;
10
11     static double SlowSpeed      = 0.10;
12     static double GoalDistance   = 24.0;
13     static double CommunityDistance = 18*12 + 8;
14
15     static double FastSpeed      = 0.25;
16     static double BalanceSpeed   = 0.15;
17
18     static double InclineAngle   = 10.0;
19     static double BalanceAngle   = 3.0;
20
21     static double ArmTolerance   = 1.0;
22     static double LiftTolerance  = 1.0;
23
24     static double DroolDuration = 1.0;
25
26     /* Do absolutely nothing. This is used as a safety in case
27 things go horribly wrong and Auton modes do not execute
28 as intended.
29 */
30
31     public static void Nothing () {
32         switch ( Stage.StageNumber ) {
33             default:
34                 Stage.Last();
35                 break;
36         }
37     }
38
39     /*
40 The "Balance" path is used when the elevator assembly
41 is no longer working and we become a defense only robot.
42 */
43
44     public static void Balance () {
45         switch ( Stage.StageNumber ) {
46             case 0:
47                 Autopilot.DriveSouth( FastSpeed );
48                 Stage.WaitForIncline( InclineAngle );
49                 break;
50
51             case 1:
52                 Autopilot.DriveSouth( BalanceSpeed );
53                 Stage.WaitForBalance( BalanceAngle );
54                 break;
55
56             default:
57                 Stage.Last();
58                 break;
59         }
60     }
61
62     /* The "Any" paths are used to simply place a cone or cube
63 without balancing. Useful for when another team balances
64 and we need to stay out of the way.
65 */

```

```
66
67     public static void Any_1st () {
68         switch ( Stage.StageNumber ) {
69             case 0:
70                 Autopilot.DriveNorth( SlowSpeed );
71                 Stage.WaitForDistance( GoalDistance );
72                 break;
73
74             case 1:
75                 Autopilot.DriveSouth( FastSpeed );
76                 Stage.WaitForDistance( CommunityDistance );
77                 break;
78
79             default:
80                 Stage.Last();
81                 break;
82         }
83     }
84
85     public static void Any_2nd () {
86         switch ( Stage.StageNumber ) {
87             case 0:
88                 Arm.SetLO();
89                 Lift.SetHI();
90                 Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
91                 break;
92
93             case 1:
94                 Roller.Drool();
95                 Stage.WaitForDuration( DroolDuration );
96                 break;
97
98             case 2:
99                 Arm.SetHI();
100                Roller.Stop();
101                Stage.WaitForArm( 1 );
102                break;
103
104             case 3:
105                 Lift.SetLO();
106                 Stage.WaitForLift( 1 );
107                 break;
108
109             case 4:
110                 Autopilot.DriveSouth( FastSpeed );
111                 Stage.WaitForDistance( CommunityDistance );
112                 break;
113
114             default:
115                 Stage.Last();
116                 break;
117         }
118     }
119
120     /*
121     The "Center" paths are used when we start in the center of the
122     field and desire to balance.
123     */
124     public static void Ctr_1st () {
125         switch ( Stage.StageNumber ) {
126             case 0:
127                 Autopilot.DriveNorth( SlowSpeed );
128                 Stage.WaitForDistance( GoalDistance );
129                 break;
130
131             case 1:
132                 Autopilot.DriveSouth( FastSpeed );
133                 Stage.WaitForIncline( InclineAngle );
```

```

134         break;
135
136     case 2:
137         Autopilot.DriveSouth( BalanceSpeed );
138         Stage.WaitForBalance( BalanceAngle );
139         break;
140
141     default:
142         Stage.Last();
143         break;
144     }
145 }
146
147 public static void Ctr_2nd () {
148     switch ( Stage.StageNumber ) {
149     case 0:
150         Elevator.Preset3();
151         Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
152         break;
153
154     case 1:
155         Roller.Drool();
156         Stage.WaitForDuration( DroolDuration );
157         break;
158
159     case 3:
160         Elevator.Preset1();
161         Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
162         break;
163
164     case 4:
165         Autopilot.DriveSouth( FastSpeed );
166         Stage.WaitForIncline( InclineAngle );
167         break;
168
169     case 5:
170         Autopilot.DriveSouth( BalanceSpeed );
171         Stage.WaitForBalance( BalanceAngle );
172         break;
173
174     default:
175         Stage.Last();
176         break;
177     }
178 }
179
180 public static void Lft_1st () {
181     switch ( Stage.StageNumber ) {
182     case 0:
183         Autopilot.DriveNorth( SlowSpeed );
184         Stage.WaitForDistance( GoalDistance );
185         break;
186
187     case 1:
188         // Twist robot to put block fully across line.
189
190     case 2:
191         Elevator.Preset1();
192         Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
193         break;
194
195     case 3:
196         Autopilot.DriveSouth( FastSpeed );
197         Stage.WaitForDistance( CommunityDistance ); // 18 ft, 4 in
198         break;
199
200     default:
201         Stage.Last();

```

```
202         break;
203     }
204 }
205
206 public static void Lft_2nd () {
207     switch ( Stage.StageNumber ) {
208         case 0:
209             Elevator.Preset3 ();
210             Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
211             break;
212
213         case 1:
214             Roller.Drool();
215             Stage.WaitForDuration( DroolDuration );
216             break;
217
218         case 2:
219             Elevator.Preset1 ();
220             Stage.WaitForArmLift( ArmTolerance, LiftTolerance );
221             break;
222
223         case 3:
224             Autopilot.DriveSouth( FastSpeed );
225             Stage.WaitForDistance( CommunityDistance );
226             break;
227
228         default:
229             Stage.Last ();
230             break;
231     }
232 }
233
234 /*
235  The "Right" paths are exactly the same as the left
236  paths. Manipulate the item and then move away a value
237  of CommunityDistance (last set to be 18 feet, 8 inches).
238 */
239
240 public static void Rgt_1st () {
241     Lft_1st ();
242 }
243
244 public static void Rgt_2nd () {
245     Lft_2nd ();
246 }
247
248 }
```


Settings.java

```

1 package frc.robot.Hardware;
2
3 public class Settings {
4
5     // AUTON STAGES
6     public static int
7         MAX_NUMBER_OF_STAGES = 20;
8
9     // CONTROLLER PORTS
10    public static int
11        DriveStickID = 0,
12        ManipStickID = 1;
13
14    // MAXIMUM SWERVE MODULE SPEEDS
15    public static double
16        MAX_DRIVE_RATIO = 1.00;
17
18    // MODULE ASSIGNMENTS
19    public static int
20        FL_moduleNumber = 1,
21        FR_moduleNumber = 4,
22        RL_moduleNumber = 5,
23        RR_moduleNumber = 3;
24
25    // MODULE LOCATIONS
26    public static double
27        FLx = 1, FLy = 1,
28        FRx = 1, FRy = -1,
29        RLx = -1, RLy = 1,
30        RRx = -1, RRy = -1;
31
32    // FRONT SONAR
33    public static int[]
34        FrontSonar_DIO = { 3, 2 };
35
36    // CLICKS PER INCH
37    public static double
38        IN_PER_CLICK = ( Math.PI * 4 ) / EncTalonFX.kUnitsPerRevolution;
39
40    //
41    // ELEVATOR ASSIGNMENTS
42    //
43    // ARM
44    public static int
45        Am_CANID = 15;
46
47    // ROLLER (Left, Right)
48    public static int[]
49        Roller_CANID = { 30, 35 };
50
51    // LIFT
52    public static int
53        LiftR_CANID = 20,
54        LiftL_CANID = 21;
55
56    public static int[]
57        LiftSonar_DIO = { 0, 1 };
58
59 }

```

Stage.java

```
1 package frc.robot.Hardware;
2
3 import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
4 import frc.robot.Elevator.Arm;
5 import frc.robot.Elevator.Lift;
6
7 public class Stage {
8
9     public static double   AutonStartTime;
10    public static double   AutonFinalTime;
11    public static double   StageStartTime;
12
13    public static int       StageNumber;
14    public static boolean   ReadyToAdvance;
15    public static double[]  StageDistance = new double[ Settings.MAX_NUMBER_OF_STAGES ];
16    public static double[]  StageTime     = new double[ Settings.MAX_NUMBER_OF_STAGES ];
17
18    public static double
19        NegTilt = 0,
20        PosTilt = 0;
21
22    public static boolean
23        DoneWithAuton = true;
24
25    public static void Initialize () {
26
27        AutonStartTime = System.currentTimeMillis();
28        DoneWithAuton  = false;
29        StageStartTime = AutonStartTime;
30        StageNumber    = 0;
31
32        for ( int i = 0; i < 5; i++ ) {
33            StageDistance[i] = 0;
34            StageTime[i]     = 0;
35        }
36    }
37
38    public static void Display () {
39        SmartDashboard.putNumber("Robot-Stage-Number",    StageNumber
40        SmartDashboard.putNumber("Robot-Auton-Time",      GetAutonDuration() );
41
42        for ( int i = 0; i < 5; i++ ) {
43            SmartDashboard.putNumber("Stage-Time-" + i,   StageTime[i] );
44            SmartDashboard.putNumber("Stage-Dist-" + i,   StageDistance[i] );
45        }
46    }
47
48    //
49    // The Next method advances to the next stage after storing Stage
50    // information. The Last method stops
51    //
52    public static void Begin () {
53        ReadyToAdvance = true;
54    }
55
56    public static void Next () {
57        StageDistance[ StageNumber ] = GetDistance();
58        StageTime      [ StageNumber ] = GetStageTime();
59
60        if ( (ReadyToAdvance == true) && (DoneWithAuton == false) ) {
61
62            ResetOdometer();
63
64            StageStartTime = System.currentTimeMillis();
65            StageNumber++;
66        }
67    }
68
69    public static void Last () {
70        DoneWithAuton = true;
71    }
72}
```

```

66     }
67 }
68
69 public static void Last () {
70     AutonFinalTime = System.currentTimeMillis();
71     DoneWithAuton = true;
72     // ReadyToAdvance = false;
73     // StageNumber = Settings.MAX_NUMBER_OF_STAGES - 1;
74
75     Autopilot.Stop();
76     Elevator.Reset();
77 }
78
79 public static void Fail () {
80     AutonFinalTime = System.currentTimeMillis();
81     ReadyToAdvance = false;
82     StageNumber = Settings.MAX_NUMBER_OF_STAGES;
83 }
84
85 //
86 // Get...Time methods are useful in auton mode to determine the amount
87 // of time that the current stage or the entire auton process has been
88 // executing.
89 //
90 public static double GetAutonDuration () {
91     return ( System.currentTimeMillis() - AutonStartTime ) / 1000.0;
92 }
93
94 public static double GetStageTime () {
95     return ( System.currentTimeMillis() - StageStartTime ) / 1000.0;
96 }
97
98 public static void WaitForDuration ( double Duration ) {
99     if ( GetStageTime() < Duration ) {
100         ReadyToAdvance = false;
101     }
102 }
103
104 //
105 //
106 //
107 public static double GetDistance () {
108     double FL = Swerve.FL_module.DriveMotor.getSelectedSensorPosition();
109     // double FR = Swerve.FR_module.DriveMotor.getSelectedSensorPosition();
110     // double RL = Swerve.RL_module.DriveMotor.getSelectedSensorPosition();
111     // double RR = Swerve.RR_module.DriveMotor.getSelectedSensorPosition();
112
113     // ABS SINCE SOME WHEELS GOING BACKWARD
114     FL = Math.abs( FL );
115     // FR = Math.abs( FR );
116     // RL = Math.abs( RL );
117     // RR = Math.abs( RR );
118
119     // return Math.abs( FL );
120     // TAKE AN AVERAGE FOR SIMPLICITY
121     // return ( FL + FR + RL + RR ) * Settings.IN_PER_CLICK / 4;
122     return ( FL / 1000 * 3/4 );
123 }
124
125 public static void ResetOdometer () {
126     Swerve.FL_module.DriveMotor.setSelectedSensorPosition( 0 );
127     Swerve.FR_module.DriveMotor.setSelectedSensorPosition( 0 );
128     Swerve.RL_module.DriveMotor.setSelectedSensorPosition( 0 );
129     Swerve.RR_module.DriveMotor.setSelectedSensorPosition( 0 );
130 }
131
132 public static void WaitForDistance ( double Distance ) {
133     if ( GetDistance() <= Distance ) {

```

```
134         ReadyToAdvance = false;
135     }
136 }
137
138 //
139 //
140 //
141 public static void WaitForHeading ( double Heading, double Tolerance ) {
142     double diff = Autopilot.HeadingDiff( Heading );
143     if ( Math.abs( diff ) < Tolerance ) {
144         ReadyToAdvance = false;
145     }
146 }
147
148 //
149 // Second draft of code to be used in auton. Drive forward until we notice an incline.
150 // At that point we advance stages and continue to drive forward until we notice a
151 // balanced condition. It would be good to also have a maximum distance travelled for
152 // each stage and fail if the condition is not met.
153 //
154 public static void WaitForBalance ( double Tolerance ) {
155     double pitch = Navigation.GetPitch();
156     if ( Math.abs( pitch ) > Tolerance ) {
157         ReadyToAdvance = false;
158     }
159 }
160
161 public static void WaitForIncline ( double Angle ) {
162     double pitch = Navigation.GetPitch();
163     if ( Math.abs( pitch ) < Angle ) {
164         ReadyToAdvance = false;
165     }
166 }
167
168 //
169 //
170 //
171 public static void WaitForArm ( double Tolerance ) {
172     if ( Math.abs( Arm.PosER ) > 1.5 ) {
173         ReadyToAdvance = false;
174     }
175 }
176
177 public static void WaitForArmLift ( double ArmTolerance, double LiftTolerance ) {
178     WaitForArm ( ArmTolerance );
179     WaitForLift( LiftTolerance );
180 }
181
182 public static void WaitForLift ( double Tolerance ) {
183     if ( Math.abs( Lift.displacement ) > 1.5 ) {
184         ReadyToAdvance = false;
185     }
186 }
187
188 // public static void WaitForWheelAlignment ( double Angle ) {
189 // // }
190 // public static void WaitForHeading ( double Heading, double Tolerance ) {
191 // // }
192 // // }
193 // // }
194 //
195 // public static boolean WaitForHeading( double targetHeading, double tolerance ) {
196 //     if ( Math.abs(Navigation.GetDelta(targetHeading)) < tolerance ) { return true; }
197 // // }
198 // // }
199 // // }
200 // public static boolean WaitForTarget( double tolerance ) {
201 //     if ( Drivetrain.TargetMin<-tolerance || Drivetrain.TargetMax>tolerance ) {
```

```
202 //      StillWorking = true;
203 //      return true;
204 //    }
205 //    else {
206 //      return false;
207 //    }
208 //  }
209 // }
210
211
212 }
```

Swerve.java

```
1 package frc.robot.Hardware;
2
3 import edu.wpi.first.math.geometry.Rotation2d;
4 import edu.wpi.first.math.geometry.Translation2d;
5 import edu.wpi.first.math.kinematics.ChassisSpeeds;
6 import edu.wpi.first.math.kinematics.SwerveDriveKinematics;
7 import edu.wpi.first.math.kinematics.SwerveModuleState;
8
9 public class Swerve {
10
11     // CHASSIS SPEEDS
12     public static ChassisSpeeds
13         RobotSpeed;
14
15     // MODULE DEFINITIONS
16     public static Module
17         FL_module,
18         FR_module,
19         RL_module,
20         RR_module;
21
22     // TRANSLATION OBJECTS
23     static Translation2d
24         FL_Trans2d,
25         FR_Trans2d,
26         RL_Trans2d,
27         RR_Trans2d;
28
29     // KINEMATICS OBJECT
30     public static SwerveDriveKinematics
31         Kinematics;
32
33     // INITIALIZE
34     public static void Initialize () {
35
36         // CHASSIS SPEEDS
37         RobotSpeed = new ChassisSpeeds( 0, 0, 0 );
38
39         // MODULE DEFINITIONS
40         FL_module = new Module( "FL", Settings.FL_moduleNumber );
41         FR_module = new Module( "FR", Settings.FR_moduleNumber );
42         RL_module = new Module( "RL", Settings.RL_moduleNumber );
43         RR_module = new Module( "RR", Settings.RR_moduleNumber );
44
45         // TRANSLATION OBJECT
46         FL_Trans2d = new Translation2d( Settings.FLx, Settings.FLy );
47         FR_Trans2d = new Translation2d( Settings.FRx, Settings.FRy );
48         RL_Trans2d = new Translation2d( Settings.RLx, Settings.RLy );
49         RR_Trans2d = new Translation2d( Settings.RRx, Settings.RRy );
50
51         // KINEMATICS OBJECT
52         Kinematics = new SwerveDriveKinematics( FL_Trans2d, FR_Trans2d, RL_Trans2d, RR_Trans2d );
53     }
54
55     public static void Display () {
56         // SmartDashboard.putNumber("Robot-vx", RobotSpeed.vxMetersPerSecond );
57         // SmartDashboard.putNumber("Robot-vy", RobotSpeed.vyMetersPerSecond );
58         // SmartDashboard.putNumber("Robot-vt", RobotSpeed.omegaRadiansPerSecond );
59
60         FL_module.Display();
61         FR_module.Display();
62         RL_module.Display();
63         RR_module.Display();
64     }
65 }
```

```

66     public static void UpdateFieldRelative ( double vx, double vy, double vt ) {
67         Rotation2d Rot2d = Rotation2d.fromDegrees( Navigation.GetYaw() );
68         ChassisSpeeds Speeds = ChassisSpeeds.fromFieldRelativeSpeeds( vx, vy, vt, Rot2d );
69         Update( Speeds );
70     }
71
72     public static void UpdateRobotRelative ( double vx, double vy, double vt ) {
73         ChassisSpeeds Speeds = new ChassisSpeeds( vx, vy, vt );
74         Update( Speeds );
75     }
76
77     private static void Update ( ChassisSpeeds Speeds ) {
78
79         // WAIT FOR WHEEL TO ADJUST TO HEADING
80         // boolean ok_to_drive = true;
81         // if ( FL_module.still_turning_flag ) { ok_to_drive = false; }
82         // if ( FR_module.still_turning_flag ) { ok_to_drive = false; }
83         // if ( RL_module.still_turning_flag ) { ok_to_drive = false; }
84         // if ( RR_module.still_turning_flag ) { ok_to_drive = false; }
85
86         // ALIGN WHEELS BEFORE TRANSLATION
87         // if ( ! ok_to_drive ) {
88         //     Speeds.vxMetersPerSecond = 0;
89         //     Speeds.vyMetersPerSecond = 0;
90         // }
91
92         // CALCULATE INDIVIDUAL MODULE STATES
93         SwerveModuleState[] ModuleStates = Kinematics.toSwerveModuleStates( Speeds );
94
95         // NORMALIZE WHEEL RATIOS IF ANY SPEED IS ABOVE SPECIFIED MAXIMUM
96         // SwerveDriveKinematics.desaturateWheelSpeeds( ModuleStates, Settings.MAX_DRIVE_RATIO );
97
98         // UPDATE ROBOT SPEEDS
99         // RobotSpeed = Kinematics.toChassisSpeeds( ModuleStates );
100
101         // UPDATE EACH MODULE
102         FL_module.Update( ModuleStates[0] );
103         FR_module.Update( ModuleStates[1] );
104         RL_module.Update( ModuleStates[2] );
105         RR_module.Update( ModuleStates[3] );
106     }
107
108 }

```

RobotRelative.java (Driver)

```
1 package frc.robot.Driver;
2
3 import edu.wpi.first.wpilibj.XboxController;
4 import frc.robot.Elevator.Arm;
5 import frc.robot.Elevator.Claw;
6 import frc.robot.Elevator.Roller;
7 import frc.robot.Hardware.Elevator;
8 import frc.robot.Hardware.Swerve;
9 import frc.robot.Mode.Teleop;
10
11 public class RobotRelative {
12
13     public static void Periodic () {
14
15         // SHORT CUT FOR MANIP STICK
16         XboxController Manip = Teleop.ManipStick;
17
18         // GET VALUES
19         double Xratio = Teleop.Xratio;
20         double Yratio = Teleop.Yratio;
21         double Tratio = Teleop.Tratio;
22
23         // JOYSTICK COMPONENTS
24         double Xmag = Math.abs( Xratio ); double Xsig = Math.signum( Xratio );
25         double Ymag = Math.abs( Yratio ); double Ysig = Math.signum( Yratio );
26         double Tmag = Math.abs( Tratio ); double Tsig = Math.signum( Tratio );
27
28         // APPLY DEADZONE AND SCALE SPEEDS: e.g., 0.20 is a 20% dead zone
29         if ( Xmag < 0.10 ) { Xmag = 0; } else { Xmag = Math.pow( Xmag-0.10, 2 ) / 2; }
30         if ( Ymag < 0.10 ) { Ymag = 0; } else { Ymag = Math.pow( Ymag-0.10, 2 ) / 2; }
31         if ( Tmag < 0.20 ) { Tmag = 0; } else { Tmag = Math.pow( Tmag-0.20, 2 ) / 2; }
32
33         if ( Manip.getStartButton() ) {
34             Arm.SetLO();
35         }
36
37         if ( Manip.getBackButton() ) {
38             Arm.SetHI();
39         }
40
41
42         // TESTING COMMANDS
43         if ( Manip.getAButtonPressed() ) {
44             Elevator.Preset1();
45         }
46
47         if ( Manip.getBButtonPressed() ) {
48             Elevator.Preset2();
49         }
50
51         if ( Manip.getYButtonPressed() ) {
52             Elevator.Preset3();
53         }
54
55         Roller.Stop();
56
57         if ( Manip.getRightBumper() ) {
58             Roller.Suck();
59         }
60
61         if ( Manip.getLeftBumper() ) {
62             Roller.Spit();
63         }
64
65         if ( Manip.getXButtonPressed() ) {
```



```
66         Claw.Toggle();
67     }
68
69     if ( Manip.getLeftStickButton() ) {
70         Arm.Arm.setSelectedSensorPosition( 90 );
71     }
72
73     // EXECUTE SWERVE
74     Swerve.UpdateRobotRelative( Xmag*Xsig, Ymag*Ysig, Tmag*Tsig );
75 }
76 }
```